

# DTF TRANSFER PRESSING INSTRUCTIONS

**Works on: Cotton, Polyester, Cotton/Poly Blends, Nylon, Leather, Cardboard, Lycra, Triblend**

**Equipment Needed: Heat Press (Household irons are NOT recommended)**

## PRESSING STEPS

- Set Your Heat Press:
  - Temperature: 280°F
  - Time: 25 seconds
  - Pressure: Medium to Heavy
- Pre-Press the Garment:
  - Press for 5 seconds to remove moisture and wrinkles.
- Place the Transfer:
  - Position the transfer on your garment (design side up, film on top).
- Press It:
  - Press for 25 seconds at 280°F using medium-heavy pressure.
- Let it Cool:
  - Cold Peel Only - Wait until the film is completely cool before peeling slowly and evenly.
- Optional Final Press:
  - Cover with parchment or Teflon sheet and press again for 5-10 seconds for added durability.

## CARE INSTRUCTIONS

- Wash inside out with cold water
- Avoid bleach or harsh detergents
- Tumble dry inside out on low to medium heat
- Do NOT iron directly on the print

*Pro Tip: Every press is a little different. We include a free test sample in every order - use it before pressing your full design!*